

SWP-3

Scan Window Protector for Opticon OPN-3002i/n and OPN-4000i/n

This custom made Scan Window Protector is made from the best grade protection foil available on the market.

Designed to fit on the following Opticon scanner models:



SWP-3



Scratch resistant



Crystal clear



Repair effect



Residue-free removal

APPLICATION INSTRUCTIONS

How to apply the Scan Window Protector (SWP):

Place the OPN, the SWP and a microfibre cloth on a solid surface which is free of dust. Then wash your hands thoroughly. Clean the scan window with the microfibre cloth to remove dust and dirt marks.

Peel the backing off halfway and begin to apply the SWP aligning it in two directions from one corner.

Caution: Do not touch the adhesive side of the SWP with your fingers!

Slowly peel off the remainder of the backing and apply the rest of the SWP to the scan window.

If the film is not positioned centrally after having been applied, use some normal sticky tape to remove it from the scan window and start again.

REMOVAL INSTRUCTIONS

Use some normal sticky tape and apply this on top of the SWP. Lift and remove the SWP from the scan window.

Clean the window with a microfibre cloth if any dust or dirt marks are visible on the scan window. A new SWP can be applied now.