

## Legal Notices

This manual and any examples contained herein are provided "as is". JNC makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability, non-infringement and fitness for a particular purpose. JNC shall not be liable for any errors or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or the examples contained herein.

Reproduction, adaptation or translation of this manual is prohibited without prior written permission of JNC Service B.V.

**CAUTION: This Quick Reference Guide may be revised or withdrawn at any time without prior notice.**

This document provides basic usage instructions and information on setting up your DOKKi docking station.

## UNPACKING



**Do NOT use a knife to open the package or contents as this may result in damage to the product(s)**

Open the outer box on the top-side. Take the CLK-1 from it's box and remove it from the (bubble)foil.

## BOX CONTENTS

- CLK-1 docking station

*Promotional items aren't listed here.*

The insertion area is as tight as possible to ensure stability for the scanner. This also means that the scanner won't fit when used in combination with any available sleeve or case (rubber, leather, etc.).



The CLK-1 will fit Opticon scanner models OPH-3001, OPH-3000, CLK-3001, CLK-3000 and SMART.

***Always check our website for the latest list of models that fit if your model isn't listed here.***



Before inserting any scanner in the dock be sure to remove the USB cover (if any). Save the USB cover in case it is needed at a later stage.



***By removing the USB cover from the scanner dust and/or moist can penetrate the connector and opening(s) behind the USB cover more easily. It is possible that the products' IP rating has been altered too. Removing any original part from the scanner could void warranty. Doing so is at your own accountability!***

## POSITIONING

The CLK-1 has rubber feet on the bottom and can be used on a flat surface. Please make sure the CLK-1 is positioned on a firm background which is level.

## POWER AND CONNECTION

Plug the USB cable into the mini USB connector in the bottom of the CLK-1. The CLK-1 is now ready for use.



CLK-1 bottom view USB connector

## CLK-1 USAGE SAMPLES

- **CHARGE ONLY**

You can use the CLK-1 as a 'charge only dock'.

Connect the other end of the USB cable to our USBC-NET2 5V/2.1A power adapter for fast and safe charging. Power adapters can be found on our website.

You can also connect it to the PC's USB port instead, but charging may be slower due to lower available charge current and it may also well be that charging isn't possible when the PC is switched off.

- **COMMUNICATION AND CHARGING (MIXED)**

You can also communicate with the PC through the CLK-1. For this connect the CLK-1 with an appropriate USB cable to a PC. The DOKKi.eu CLK-1 docking station itself does not need a separate driver, nor does it create it's own Virtual Com Port (VCP)!

### USB MSD

**Running in MSD(Mass storage Device ) mode :** In this operation mode the scanners acts as an USB memory stock, making the scanned datafile available through the Windows filesystem. Upon plugging the scanner into the PC a new drive letter will be assigned to the scanners' memory. The data file(s) can be accessed, copied and deleted just like any other file on a memory stick. In this operation mode **No driver installation is necessary.**

### USB VCP

**Running in USBvcp (USB Virtual Communication Port) mode:** In this operation mode the Opticon USB driver needs to be installed on your PC. Download the latest driver from the Opticon website if not already done so, and follow the instructions for driver installation in the corresponding manual that belongs to your scanner model.

## DOCKING YOUR SCANNER

Take the scanner in your hand with the display up and facing towards yourself. Hold it with the front side at the same angle as the front-plate of the CLK-1. Make sure the handstrap points to the right so it can slide through the right side opening. Now put the backside (at battery height) against the back-plate of the CLK-1 and let the scanner slide down towards the USB connector. Make sure you feel the USB connectors make proper contact and then gently press the scanner down into its place.



**Press firmly but never use excessive force when pressing down as this might damage the connectors!**

***Always check for obstructions on both connectors before trying to dock the scanner.***

## ACCESSORIES

- SWP-4 – Scan Window Protector
- SCR-4 – Screen Protector
- USBC-NET2 – Power Adapter 5V / 2.1A

*Check our website for availability and more information.*

## TROUBLESHOOTING

If you are experiencing any problem with the CLK-1 the first thing to check is if the scanner operates correctly when connected directly to the PC with an USB cable. Do so by plugging the USB cable that came with your scanner into your scanner and make sure the other end of the USB cable goes directly into the PC (bypassing any present HUB).

If it does function properly continue at the check-list below, otherwise the problem is with your scanner itself, the USB cable or the PC (USB port and/or driver(s)).

### Checklist

No power *1	<ul style="list-style-type: none"> <li>- Is the scanner firmly pressed into the docking station?</li> <li>- Are the cables working and properly connected?</li> <li>- Is the PC switched on?</li> </ul>
No communication *1	<ul style="list-style-type: none"> <li>- Is the scanner fully charged?</li> <li>- Are the necessary scanner drivers properly installed?</li> <li>- Do the communication settings match between scanner and the PC?</li> <li>- Are there no other programs polling on the same COM-port?</li> </ul>
*1 and if connected to a powered USB hub	<ul style="list-style-type: none"> <li>- Is the power-supply of the USB hub plugged in?</li> <li>- Is one port on the USB hub failing, or are all ports faulty?</li> <li>- Is the USB cable securely fitted on both ends?</li> </ul>



Contact your (local) dealer in case you need support or have any other question. Follow the instructions provided by your dealer.

BY OPENING THE PACKAGE OF THIS PRODUCT YOU AGREE TO BECOME BOUND  
BY THE LIABILITY AND WARRANTY CONDITIONS.

### Limited Warranty, Liability and Disclaimers

This Limited Warranty and Disclaimer extends only to products purchased directly from DOKKi.eu or a DOKKi.eu Authorized Dealer as stated on our website (<http://www.dokki.eu/dealers>).

Under no circumstance JNC will be liable for any direct, indirect, incidental, special, consequential, punitive, or exemplary damages, including but not limited to, damages for loss of profits, revenue, income, goodwill, use, data, or other intangible losses that arise from use or inability to use the CLK-1, even if JNC has been informed about the possibility of such damages.

The DOKKi.eu CLK-1 is warranted for a period of one year after purchase, covering defects in material and workmanship. JNC will repair or, at its opinion, replace products that prove to be defective in material or workmanship under proper use during the warranty period. The warranty does not apply to defects resulting from (a) improper or inadequate maintenance measures taken; (b) interfacing parts or supplies not supplied or authorised by JNC; (c) unauthorized modification or misuse; (d) operation outside the applicable environmental parameter limits specified for the product; or (e) improper site preparation or maintenance for installation.