

## Legal Notices

This manual and any examples contained herein are provided "as is". JNC makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability, non-infringement and fitness for a particular purpose. JNC shall not be liable for any errors or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or the examples contained herein.

Reproduction, adaptation or translation of this manual is prohibited without prior written permission of JNC Service B.V.

**CAUTION: This Quick Reference Guide may be revised or withdrawn at any time without prior notice.**

This document provides basic usage instructions and information on setting up your DOKKi docking station.

## UNPACKING



**Do NOT use a knife to open the package or contents as this may result in damaging the product(s)**

Open the outer box on the top-side. Take the CMT-6SPC from it's box and remove the bubble-foil.



CMT-6SPC with OPN2001's & OPN2006's + SPC-2-GRY and SPC-2-BLU

## BOX CONTENTS

- CMT-6SPC docking station
- power adapter
- USB cable

*Promotional items aren't listed here.*

FITS OPTICON + DOKKI
OPN2001 + SPC2
OPN2005 + SPC2
OPN2006 + SPC2

The CMT-6SPC is designed to operate with Opticon scanner models OPN-2001, OPN-2005 and OPN-2006 with the DOKKi SPC-2-xxx silicone protection case fitted.

*Always check our website for the latest list of models that fit if your model isn't listed here.*



**The insertion area of the CMT-6SPC is specifically designed for use with the OPN scanner with our SPC-2-xxx silicone protection case fitted (SPC-2-xxx, where xxx stand for color/option). Only use compatible scanners with our SPC-2 installed. Using OPN's without our SPC-2-xxx or with any other cover may result in damaging the docking station and/or OPN scanner!**



**Other models (for example the OPN-2002, OPN-2003 and OPN-2004) won't fit. Trying to insert unlisted models will result in damage to the CMT-6SPC and other scanner model!**

## POSITIONING

The CMT-6SPC has rubber feet on the bottom and can be used as a desk-stand. Please make sure the CMT-6SPC is positioned on a firm background which is levelled.

## POWER AND CONNECTION

After unpacking and positioning, simply connect the power adapter to the back of the CMT-6SPC and the other end in the wall outlet.

## CMT-6SPC USAGE SAMPLES

- **CHARGE ONLY**

You can use the CMT-6SPC as a 'charge only dock'.

Simply plugin the power adapter that is supplied with the CMT-6SPC. All ports are now ready to charge.

- **COMMUNICATION AND CHARGING (MIXED)**

You can also use all ports to communicate with the PC. Besides the power adapter additionally connect the CMT-6SPC with the supplied USB cable to a PC.

***Intended use is for the OPN2001 in VCP COM mode. Other modes (USB HID) and models using the 'OPN2001 simulation' application may run unstable and result in data loss.***

Remember: each position on the CMT-6SPC will create it's own random Virtual Com Port (VCP) on the PC when a scanner is inserted, so make sure your software is able to handle this!

### ***DRIVER INSTALLATION – ONLY NECESSARY WHEN USING THE CMT-6SPC FOR COMMUNICATION TO PC***

The DOKKi CMT-6SPC itself does not need a separate driver. The only driver that needs to be installed on your PC is the appropriate driver for your scanner model (if necessary) that you wish to use. If not already done so, please follow the instructions for the Opticon driver installation in the corresponding manual that belongs to your scanner model.

## DOCKING YOUR SCANNER

Hold the scanner between your thumb and index finger on the OPN's body where USB connector is situated in the side (thus, not in the middle but more to the left side, USB connector pointing downward). Simply connect your scanner to the docking station by gently placing the OPN over the CMT-6SPC to align the connectors. When aligned press the scanner down to secure the connection.



CMT-6SPC: docking your scanner



**Press firmly but never use excessive force when pressing down as this might damage the connectors!  
Check for obstructions on both connectors and retry connection.**

## ACCESSORIES

Please check our website for available accessories.

## TROUBLESHOOTING

If you are experiencing any problem with the docking station the first thing to check is if the scanner functions correctly when connected directly to the PC with an USB cable. Do so by plugging the USB cable that came with your scanner into your scanner and make sure the other end of the USB cable goes directly into the PC (bypassing any present HUB).

If it does function properly continue at the checklist below, otherwise the problem is with your scanner itself, the USB cable or the PC (USB port and/or driver(s)).

### Checklist

No power *1	<ul style="list-style-type: none"> <li>- Is the scanner firmly pressed into the docking station?</li> <li>- Are the cables working and properly connected?</li> <li>- Is the PC switched on?</li> </ul>
No communication *1	<ul style="list-style-type: none"> <li>- Is the scanner fully charged?</li> <li>- Are the necessary scanner drivers properly installed?</li> <li>- Do the communication settings match between scanner and the PC?</li> <li>- Are there no other programs polling on the same COM-port?</li> </ul>
<i>*1 and if connected to a powered USB hub</i>	<ul style="list-style-type: none"> <li>- Is the power-supply of the USB hub plugged in?</li> <li>- Is one port on the USB hub failing, or are all ports faulty?</li> <li>- Is the USB cable securely fitted on both ends?</li> </ul>

If you have any questions regarding the use of the DOKKi.eu docking station please contact your dealer.

BY OPENING THE PACKAGE OF THIS PRODUCT YOU AGREE TO BECOME BOUND  
BY THE LIABILITY AND WARRANTY CONDITIONS.

### Limited Warranty, Liability and Disclaimers

This Limited Warranty and Disclaimer extends only to products purchased directly from DOKKi.eu or a DOKKi.eu Authorized Dealer as stated on our website (<http://www.dokki.eu/dealers>).

Under no circumstance JNC will be liable for any direct, indirect, incidental, special, consequential, punitive, or exemplary damages, including but not limited to, damages for loss of profits, revenue, income, goodwill, use, data, or other intangible losses that arise from use or inability to use the docking station, even if JNC has been informed about the possibility of such damages.

This DOKKi.eu docking station is warranted for a period of one year after purchase, covering defects in material and workmanship. JNC will repair or, at its opinion, replace products that prove to be defective in material or workmanship under proper use during the warranty period. The warranty does not apply to defects resulting from (a) improper or inadequate maintenance measures taken; (b) interfacing parts or supplies not supplied or authorised by JNC; (c) unauthorized modification or misuse; (d) operation outside the applicable environmental parameter limits specified for the product; or (e) improper site preparation or maintenance for installation.

Always return the product through the dealer where initially bought. Follow the instructions provided by your dealer.